



Optional:  
Fan On/Off Switch  
For Mounting to All

## TECHNICAL INFORMATION

In the interest of continuing product improvement,  
we reserve the right to change models,  
specifications, and/or features without prejudice.

PROJECT: \_\_\_\_\_  
LOCATION: \_\_\_\_\_  
ARCHITECT: \_\_\_\_\_  
ENGINEER: \_\_\_\_\_  
CONTRACTOR: \_\_\_\_\_  
DATE: \_\_\_\_\_ SALES ENGINEER: \_\_\_\_\_

[www.monoxivent.com](http://www.monoxivent.com)

[info@monoxivent.com](mailto:info@monoxivent.com)

309-794-1000

Page: HRSO-13

### SERIES DMSHR

#### OPTIONAL DIRECT MOUNT FAN ON/OFF SWITCH

- |                                               |                                                 |
|-----------------------------------------------|-------------------------------------------------|
| A - Sealed Mounting Box                       | E - Hose Reel Support Mounting Frame            |
| B - Box Cover Plate                           | F - On/Off Switch Control Assembly              |
| C - On/Off Toggle Switch **                   | G - bumper Pad for Activating the On/Off Toggle |
| D - (2) Slot Cuts for Adjustment of Box Depth |                                                 |

#### **ON/OFF SWITCH FUNCTION:**

The switch assembly is mounted to the support frame of the hose reel. The depth of the toggle is set to be semi-flush with the switch box. All other depth settings are set using the slotted holes in the switch box. The bumper pad is mounted to the end flange of the hose reel and tightened into place. With the toggle switch firmly in the box, the reel is turned so the bumper pad is directly in line with the switch. The final depth of the toggle box is now set so the bumper and toggle will make slight contact and the toggle arm is either turned on or off by the bumper pad.

The bumper pad is mounted to the end flange of the reel and turns with the reel as the hose is uncoiled or recoiled. As the hose is uncoiled the bumper pad triggers the toggle switch to the on position, thus completing an electrical circuit and the fan start-up begins. As the hose is recoiled, the bumper pad now triggers the toggle switch to the off position, thus disconnecting the electrical circuit. At this point "fan shut-down" occurs.

The switch is only used to complete the electrical circuit. The toggle switches are usually tied to a control box or a starter package for the blower that is in use. Toggle switches may be wired in parallel fashion to activate one central blower or the switches can be used to activate a single direct mount blower on the hose reel.

#### **\*\* SWITCH SPECIFICATIONS:**

##### **RATING:**

- 15 AMP @ 125 VAC
- 10 AMP @ 250 VAC
- 3/4 HP @ 250 VAC